Single phase, Heatsink separated type SSR

NEW

Features

- Increase user convenience with general and small design
- Superior dielectric strength: 4,000VAC
- Improved reliability by maximizing heat protection efficiency with ceramic board
- Supports Zero cross turn-on/Random turn-on type
- Checks input status by Input LED(green)





Please read "Caution for your safety" in operation manual before using.

(€ cMus

Ordering information

SR /	1 - 1	4 20 R		
		Function	No Mark	Zero cross turn-on
			R	Random turn-on
			15	15A
		Rated load current	25	25A
		(resistive load) Load voltage(rated)	40	40A
			50	50A
			75	75A
			2	24-240VAC
		4	48-480VAC	
	Input v	oltage(rated)	1	4-30VDC
Control phase			4	90-240VAC
			1	Single phase
Item			— SRC	Solid State Relay(detachable heatsink type)

Model	Input voltage	Rated load current	Load voltage	Zero cross/Random turn-on		
SR1-1215	4-30VDC	454				
SR1-4215	90-240VAC	15A				
SR1-1225	4-30VDC	054				
SR1-4225	90-240VAC	25A				
SR1-1240	4-30VDC	404	04.040\/A.0	7		
SR1-4240	90-240VAC	40A	24-240VAC	Zero cross turn-on		
SR1-1250	4-30VDC	504				
SR1-4250	90-240VAC	50A				
SR1-1275	4-30VDC	75 4				
SR1-4275	90-240VAC	75A				
SR1-1415	4.20V/DC			Zero cross turn-on Random turn-on Zero cross turn-on		
SR1-1415R	4-30VDC	15A				
SR1-4415	90-240VAC					
SR1-1425	4-30VDC			Zero cross turn-on		
SR1-1425R	4-30VDC	25A		Random turn-on		
SR1-4425	90-240VAC			Zero cross turn-on		
SR1-1440	4-30VDC			Zero cross turn-on Random turn-on		
SR1-1440R	4-30VDC	40A	48-480VAC			
SR1-4440	90-240VAC			Zero cross turn-on		
SR1-1450	4-30VDC			Zero cross turn-on		
SR1-1450R	4-30VDC	50A		Random turn-on		
SR1-4450	90-240VAC			Zero cross turn-on Zero cross turn-on Random turn-on		
SR1-1475	4-30VDC					
SR1-1475R	4-30VDC	75A				
SR1-4475	90-240VAC			Zero cross turn-on		

(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity

(E) Pressure sensor

> F) Rotary

(G)

Socket

Temp. controller

(I) SSR/ Power controller

(J) Counter

K) Timer

>) inel eter

(M) Tacho/ Speed/ Pulse meter

>) splay iit

nsor ensor

(P) Switching mode power supply

> Q) tepper iotor& river&Controller

(R) Graphic/ Logic panel

> S) Field network device

> T) Software

(U) Other

Specifications

O Input

		4-30VDC input voltage	90-240VAC input voltage		
Input voltage range		4-32VDC	85-264VACrms(50/60Hz)		
Max. input current		9mA(Zero cross turn-on), 13mA(Random turn-on)	7mArms(240VACrms)		
Pick-up voltage		4VDC	85VACrms		
Drop-out voltage		1VDC	10VACrms		
Turn-on	Zero cross turn-on	Max. 0.5 cycle of load source + 1ms	May 15 avale of load source 1 1mg		
time	Random turn-on	Max. 1ms	Max. 1.5 cycle of load source + 1ms		
Turn-off time		Max. 0.5 cycle of load source + 1ms	Max. 1.5 cycle of load source + 1ms		

Output

		24-240VAC load voltage					48-480VAC load voltage					
Load voltage range(50/60Hz)		24-264VACrms(50/60Hz)					48-528VACrms(50/60Hz)					
Rated load current Ta=25°C	Resistive load (AC-51)	15Arms	25Arms	40Arms	50Arms	75Arms	15Arms	25Arms	40Arms	50Arms	75Arms	
	Motor load (AC-53a)	_						8Arms		15Arms		
Min. load current		0.15Arms	5Arms 0.2Arms 0.5Arms			0.5Arms						
Max. 1cycle surge current (60Hz)		190A	270A	330A	1000A		300A	500A		1000A		
Max. non-repetitive surgecurrent(I ² t, t=8.3ms)		150A ² S	300A ² S	500A ² S	4000A ² S		350A ² S	1000A ² S	,	4000A ² S		
Peak voltage(non-repetitive)		600V 1200V(zero cross turn-on), 1000V(randor						0V(random	turn-on)			
Leakage current(Ta=25°C)		Max. 10mArms										
Output on voltage drop[Vpk] (Max. load current)		Max. 1.6V										
Static off-state dv/dt		500V/µs										

[※] For controlling motor load, use the product which load voltage range is within 48-480VACrms.


General Specifications

ion	UL508, CSA22.2 No.14 and IEC/EN 60947-4-3				
strength(Vrms)	4000VAC 50/60Hz 1min.(input-output, input/output-case)				
resistance	Min. 100MΩ(at 500VDC megger)				
)	Green				
Ambient temperature	-30 to 80°C, storage: -30 to 100°C(Rated load current capacity is different based on the surrounding temperature. Refer to ' ■ SSR Derating curve'.)				
Ambient humidity	45 to 85%RH, storage: 45 to 85%RH				
ninal connection	Min. 1×0.5mm²(1×AWG20) Max. 1×1.5mm²(1×AWG16) or 2×1.5mm²(2×AWG16)				
rminal connection	Min. 1×1.5mm ² (1×AWG16) Max. 1×16mm ² (1×AWG6) or 2×6mm ² (2×AWG10)				
ninal fixed torque	0.75 to 0.95N·m				
rminal fixed torque	1.6 to 2.2N·m				
ht	Approx. 73g				
	strength(Vrms) resistance Ambient temperature Ambient humidity ninal connection rminal connection ninal fixed torque rminal fixed torque				

- $\ensuremath{\mathbb{X}}$ For wiring the terminal, an O-ring terminal must be used.
- 💥 Environment resistance is rated at no freezing or condensation.

Dimensions


(unit: mm)



I-6 Autonics


Heatsink separated Type SSR


Connections




SSR Characteristic curve

© SR1-1215/4215







OSR1-1415/1415R/4415




SR1-1440/1440R/4440




OSR1-1225/4225




© SR1-1275/1475/1475R/4275/4475



O SR1-1425/1425R/4425



SR1-1250/1450/1450R/4250/4450



(A) Photo electric sensor

(B) Fiber optic sensor

(C) Door/Area sensor

(D) Proximity sensor

(E) Pressure

(F) Rotary

(G) Connector/

(H) Temp.

> (I) SSR/ Power controller

(J) Counter

(K) Timer

(L) Panel meter

(M) Tacho/ Speed/ Pulse meter

(N) Display unit

> D) ensor

(P) Switching mode power supply

(Q) Stepper motor&

(R) Graphic/ Logic panel

(S) Field network device

(T) Software

(U) Other

Autonics 1-7

SR1 Series

Proper usage

Migh temperature caution

Make sure do not touch the heat sink or the unit body while power is supplied or right after load power is turned off. If not, it may cause a burn.

Caution for using

- 1. Attach a heatsink and ventilate for smooth convection current. If not, congested heat transfer may cause product failure or malfunction.
- 2. For mounting multiple SSR, please keep certain installation intervals for heat prevention. For horizontal installation (when the heights of input part and output part are equal), it is recommended to apply less than 50% of the rated load current.
- 3. Make sure do not touch the heatsink or the unit body while power is supplied or right after load power is turned OFF. If not, it may cause a burn.
- 4. Connect the proper cable for the rated load current with output terminal.
- 5. Use rapid fuse of which I2t is under 1/2 of SSR I2t in order to protect the unit from load's short- circuit current.
- 6. In case of a short-circuit please replace the fuse with a 1/2 of SSR I2t value specified semiconductor protective type.
- 7. In case that load's current is lower than SSR min. load current, connect dummy resistance to the load in parallel so as to make load's current higher than SSR min. load current.
- 8. When selecting phase control with random turn-on model, install the noise filter between load and load's source.
- 9. Make sure that the screw on output terminal is tightly fastened. Using the unit with loose bolt may cause product failure or malfunction.
- 10. Do not touch the load's terminal even if output is OFF. It may cause electric shock.
- 11. The signal input of the 4-30VDC model should be supplied by the insulated and limited voltage/current or by Class 2 power supply.
- 12. To attach the heatsink, use Thermal Grease as below or that of equal specification.
 - Thermal Grease: GE TOSHIBA(YG6111), KANTO-KASEI(FLOIL G-600), SHINETSU(G746)
- 13. Proper application environment (Avoid following environments to install)
- ① Where temperature/humidity is beyond the specification
- ② Where dew condensation occurs due to temperature change
- 3 Where inflammable or corrosive gas exists
- Where direct rays of light exist
- ⑤ Where severe shock, vibration or dust exists
- (6) Where near facilities generating strong magnetic forces or electric noise
- 14. Installation environment
- 1 It shall be used indoor
- 2 Altitude Max. 2,000m
- 3 Pollution Degree 2
- 4 Installation Category III

1-8 **Autonics**